## M20/M20A1 AND M28 COLLECTIVE PROTECTION EQUIPMENT (CPE) HOT WEATHER/DESERT OPERFATION

This abbreviated checklist is not to be used as a replacement for the -10 series Tech Manuals or any other PMCS guide

## GENERAL

To ensure the reliability of your equipment and provide the best protection possible, follow these general guidelines:

- Keep all items in unopened, individual protective packaging until ready to use.
- 2. If possible, place tarps, covers over filters, shelters to protect them from dust and sand accumulation.
- 3. Ensure all electrical connections, ducts, and hoses are tight and properly installed.
- Before operating any system or item identified in the following paragraphs, read the appropriate TMs pertaining to that equipment.
- Cover power cords with expendable liquid-proof tarps to protect them from liquid agent contamination.

## M20/M20A1 AND M28 COLLECTIVE PROTECTION EQUIPMENT (CPE)

- Operate the M20/M20A1 CPE indoors only. Operation of the M28 CPF is used only with the TEMPER Shelter. The CPE is most effective when entries are limited during continuous chemical attack
- Do not cut or tear shelter in an attempt to increase airflow or create a breeze.
- Read all warning labels relating to electric shock and noise hazards before operating motor blower.

Approved for public release: distribution is unlimited Distributor: U.S Training Support Center March 2006

## M20/M20A1 AND M28 COLLECTIVE PROTECTION EQUIPMENT (CPE) (continued)

- Inspect motor blower every twelve (12) hours during continuous operation.
- Do not set motor blower near engine exhaust. The Hermetically Sealed Filter Canister (HSFC) will not filter engine exhaust gas containing carbon monoxide.
- Be careful not to use excessive force when entering Protective Entrance (PE) so that PE door does not tear or stretch.
- Do not prop door slits open to increase airflow through shelter.