GTA# 43-01-073

M3A4 SMOKE GENERATOR HOT WEATHER/DESERT OPERATION

This abbreviated checklist is not to be used as a replacement for the -10 series Tech Manuals or any other PMCS guide

<u>General</u>. It is important that smoke generators be inspected and maintained more frequently than normal. Problems can occur with these systems as a result of sand and dust clogging lines, filters and heads.

WARNING

Keep portable fire extinguishers properly charged and readily available during smoke generator use.

- Clean mud and sand from smoke generator before, during and after use.
- 2. Check for contamination of fuel and fog oil supplies.
- 3. Keep gas and kerosene caps securely tightened on cans when not in use.
- 4. Keep fuel tank cap securely tightened on fuel tank except when fueling.
- 5. Fill fuel tank as often as possible.
- 6. Keep bungs securely tightened on fog oil drums when not in use.
- 7. Take tools out of tool box when operating and leave tool box lid open when operating.
- 8. Keep engine heads extra clean. Inspect them often for clogging due to sand.
- 9. When opening access covers on fog oil pump, take precaution to prevent sand and dust from entering.
- 10. Close access covers on fog oil pump during operation.
- 11. Clean filters after use and as needed.
- 12. Keep magneto rack clean and greased with correct grease.

Approved for public release: distribution is unlimited Distributor: U.S Training Support Center March 2006

M3A4 SMOKE GENERATOR

- 13. Maintain magneto and air pumps.
- 14. Inspect sediment strainer.
- 15. Drain condensation from gas tank each morning.
- 16. Keep float adjuster tubes free of sand.
- 17. Do not let hoses lie on the ground.

Reference: TM 3-1040-276-10